



VD961a is an exit sensor with 3 separate sensitivity outputs.
 VD963a is a presence sensor with 3 separate sensitivity outputs.
 VD962a and VD964a are pulse & presence sensor with sens adjust.

Magna uses ambient magnetic fields. The sensors zero to the local magnetic conditions on powered up. Sensors must not be within a steel framed building or within 0.5m of an iron man hole cover, drain or large ferrous mass. Magna sensors are designed to be fitted to the centre of the road. Test the location before fixing in the ground. Contacts are volt free.

1. Position


The sensor is mounted in the road centre clear of moving steelwork. **Presence sensors** need to be positioned 2m or more from metal gates. Wooden gates have no effect.

We recommend **exit sensors** are positioned 3m or more from the nearest moving gate part, mainly for driver for convenience.


Test the sensor in position before burying. It can be moved if necessary. It resets on each power up, so can be moved several times.

Placing Magna in a non metallic pipe pre-laid in the road is highly recommended.

...for presence




... for exit



2. Fitting

The sensor is fully waterproof. Depth is not critical for operation. When fitting in a drilled hole, the middle should be over **150mm** deep with a min cable bend radius of **75mm** for stability and protection.


The sensor can be set in any orientation. A hole drilled at an angle is a simple and effective option setting it deep enough to be protected, and reducing cable radius. A 20mm drill bit is just big enough.



When setting the lead in black top, use a packer or sand layer as protection against hot pitch sealing. Setting in a sand course below **paving** is ideal. Poly-pipe is also recommended for fitting in gravel.

3. Running the cable


Run the yellow cable back to the control panel. The Magna wires direct to control PCB. A stable 12Vdc supply is recommended. A yellow marker tag is provided to identify the connections.




4. Connections

Sensors power wires are red and black, non-polarised, so connected either way around. 16-30Vac or 12-30Vdc


The solid state outputs are only for switching control panel inputs, 100mA maximum.




VD961a wiring




VD963a wiring



VD964a wiring



VD962a wiring





VD961a and VD963a have no adjustment, but for wire selection. VD962a and VD964a sensitivity can be adjusted during power up. A multi-meter is useful for trouble shooting. Only qualified technicians are authorised to work on gate automation systems. Technical help may be withheld if this cannot be confirmed.

5A. Exit sensor function

VD961a has 3 sensitivity outputs. Pulse is 3 sec N/O (normally open).
 Connect to **GREEN** and **YELLOW** for **HIGH** sensitivity
 Connect to **YELLOW** and **BROWN** for **MID** sensitivity
 Connect to **GREEN** and **BROWN** for **LOW** sensitivity

5B. Presence function

VD963a has 3 sensitivity outputs. Presence N/O is extended for 3 secs.
 Connect to **GREEN** and **BROWN** for **HIGH** sensitivity
 Connect to **YELLOW** and **BROWN** for **MID** sensitivity
 Connect to **GREEN+YELLOW** and **BROWN** for **LOW** sensitivity

| Set as an exit sensor VD961a only | | |
|---|---|---------------------|
| Red & Black | 16-30Vac or 12-30Vdc either way around | <p>N/O pulse</p> |
| Green/Yellow Yellow/Brown Green/Brown | Pulse N/O 3 sec, starting from first point of detection | |
| Set as a presence sensor VD963a only | | |
| Red & Black | 16-30Vac 12-30Vdc either way around | <p>N/C presence</p> |
| Grn/Brn Yel/Brn Gn+Ye/Brn | N/C for presence off while car is detected | |

6. Manual sensitivity setting VD962a and VD964a

On first power up these sensors (VD296A and VD964A) begin on a default sensitivity. This section describes how to adjust sensitivity. After changes are made the device will power up on the new setting. Always clear any vehicles near the detection area before power up. Normal operation mode takes 5 seconds to power up. In manual operation mode the unit takes 30 seconds to power up. Reset the sensor whenever it is moved.

Set Sensitivity manually

To enter manual setting, switch power on for less than 1 second then back off again. Switch power up again. The sensor is now in setting mode.



The pulse (GREEN) comes on for 3 seconds to indicate setting mode. Then presence (YELLOW) starts to flash slowly. The number of flashes denotes sensitivity. Switch off on the 4th flash to set sensitivity 4.



- 1 Flash = max sens
- 5 Flashes = min sens
- DEFAULT=3 Flashes

N.B. the fewer the flashes, the higher the sensitivity

Factory Reset

Follow the routine for setting sensitivity, but do not set a sensitivity by switching off. This takes about 10 secs. No sensitivity is chosen, so it reverts to factory default.



Factory reset is recommended after a sensor has been moved.


View Sensitivity



When the sensor is powered up, it will flash the sensitivity level quickly on the YELLOW output. The example above is sensitivity level 4. However, there is no sensitivity report if the sensor is in factory default (level 3).

7. Sensitivity setting VD962a using VDMA

Most gate control panels have indicators to show the input state. Troubleshooting is easier if this sensor is the only device connected to the controller's input terminal,



The optional VDMA is used to setup a sensor independent of the control panel. Connect to the VDMA as shown. Unless still set to default, the VDMA yellow LED flashes N times, where N is the sensor's sensitivity setting. The setting will be saved on power down. If a sensor is moved, it must be powered down and restarted in its new location to re-calibrate.

Factory Reset

To reset, press power button twice within 1 sec then leave for 10 secs to re-calibrate. Sensitivity level will be returned to mid range.

Sensitivity Setting

To change sensitivity, press power button twice. The green LED lights for 3 secs, then yellow LED will begin flashing slowly. To set sensitivity "4", press the power button on or just after the 4th flash. There are 5 sensitivity settings. Sensitivity 5 is the lowest level.

VD964a connections → Only yellow LED works with VD964a. Green does not.

NB Setting up in manual for one vehicle will not guarantee it will activate on all other vehicles