



C Prox Ltd (inc Quantek)

Unit 11 Callywhite Business Park, Callywhite Lane, Dronfield, S18 2XP

+44(0)1246 417113 sales@cproxltd.com www.quantek.co.uk

Disabled Toilet Locking System – 2 Button User Guide

Step 1 - If the toilet is vacant, shown by the blue LED, either open the door manually or touch the sensor for assisted entry.



Step 2 - Once inside the toilet and the door has fully shut behind you, touch the inside sensor (which will look like the pictures below). The door will lock and the light will turn red to indicate that it is locked.



Step 3 - When you are ready to leave, press the same sensor as above. The door will unlock, the light will turn blue and the door will open.

In the event of an emergency the green break glass can be pressed to exit. The external key switch can be used to gain entry from the outside.